

ANSI CUT LEVELS & APPLICATIONS

ANSI CUT RESISTANT LEVELS (GRAMS)

APPLICATION BY CUT LEVEL



LIGHT CUT HAZARDS (200)

MATERIAL HANDLING, SMALL PARTS ASSEMBLY (SHARP EDGES), PACKAGING, WAREHOUSE, GENERAL PURPOSE, FORESTRY, CONSTRUCTION



LIGHT/MEDIUM CUT HAZARDS (500)

MATERIAL HANDLING, SMALL PARTS ASSEMBLY (SHARP EDGES), PACKAGING, WAREHOUSE, GENERAL PURPOSE, FORESTRY, CONSTRUCTION, PULP AND PAPER, AUTOMOTIVE ASSEMBLY



LIGHT/MEDIUM CUT HAZARDS (1000)

MATERIAL HANDLING, SMALL PARTS ASSEMBLY (SHARP EDGES), PACKAGING, WAREHOUSE, GENERAL PURPOSE, FORESTRY, CONSTRUCTION, PULP AND PAPER, AUTOMOTIVE ASSEMBLY



MEDIUM CUT HAZARDS (1500)

APPLIANCE MANUFACTURING, BOTTLE AND LIGHT GLASS HANDLING, CANNING, DRYWALL WORK, ELECTRICAL, CARPET INSTALLATION, HVAC, PULP AND PAPER, AUTOMOTIVE ASSEMBLY, METAL FABRICATION AND HANDLING, PACKAGING, WAREHOUSE, AEROSPACE INDUSTRY, FOOD PREP/PROCESSING



MEDIUM/HEAVY CUT HAZARDS (2200)

METAL STAMPING, METAL RECYCLING, PULP AND PAPER (CHANGING SLITTER BLADES), AUTOMOTIVE ASSEMBLY, METAL FABRICATION, SHARP METAL STAMPINGS, GLASS MANUFACTURING, WINDOW MANUFACTURING, RECYCLING PAINT/SORTING, HVAC, FOOD PREP/PROCESSING, MEAT PROCESSING, AEROSPACE INDUSTRY



HIGH CUT HAZARDS (3000)



HIGH CUT HAZARDS (4000)



HIGH CUT HAZARDS (5000)



HIGH CUT HAZARDS (6000)



WORK HARD.
WEAR BOSS.®

@BossGloves

fb.com/BossGloves

www.bossgloves.com

800-447-4581